



GLASS WASHER



Disassembling instructions :

1. Pick up the plastic ring.
 2. Pick up the expanded brush from the top.
 3. Hold the middle brush, and turn left to loosen it.
- # Be careful not to overturn the middle brush.
Please follow 3-2-1 procedure for assembling.

Instructions :

1. Place the washer securely in the sink; fill with warm water and mild dish detergent.
2. Place the cup upside down in the washer; wiggling the cup back and forth to wash.
3. The excess soapy water can be drained through the tube underneath the washer.

If there are no soap bubbles in the water, refill or switch to different liquid detergent.

Beer Mug Washer

啤酒杯洗杯器

Material : All Nylon

Item Specification :

Oval Shape Size : $\varnothing 22(L) \times \varnothing 18(W) \times 26.5(H)$ cm

Stick : 21.5cm

Color : Transparent Gray /Transparent Blue

Item No. : BW-07B

Glass Washer

GLASS WASHER



Dual Brush with Sponge

泡棉洗杯器

Brush Material : Nylon + Sponge:TPU

Item Specification :

Base : 18 x 10 x 2cm

Stick : 16.5cm

Item No.: BW-02S-06NS-01 / BW-02S-06NS-02

Aluminum Round Glass Washer

鋁製圓桶洗杯器

Bristle Material : All Nylon

Item Specification :

Size : Ø 15.8 x 18.6cm , Stick : 14.5cm

Item No. : BW-01S-01N

Glass Washer-Self Contained Round

圓形藍桶洗杯器

Bristle Material : All Nylon

Item Specification :

Size : Ø 15 x 19cm , Stick : 16.5cm

Item No. : BW-01PSS-01N

Triple Glass Washer-Frizzled/Straight

三刷毛塑料底盤洗杯器-捲毛/直毛

Bristle Material : All Nylon

Item Specification :

Base : 18 x 10 x 2cm

Stick : 16.5cm / 21.5cm / 23.5cm

Item No. : BW-02F / BW-02S

5 Brushes with Aluminum Base

五刷毛鋁製底盤洗杯器

Bristle Material : All Nylon

Item Specification :

Base : Ø 13.8cm

Stick : 14.5cm / 21.5cm

Item No. : BW-03S-01N / BW-03S-02N

Single Glass Washer

單支塑料底盤洗杯器

Bristle Material : All Nylon

Item Specification :

Base : Ø 9.8 x 2cm

Stick : 16.5cm / 21.5cm

Item No. : BW-06S